

1

Start with a foam cantilever coping profile of your choice. (9 profiles to choose from)

2

Assess pool shape. Tape form in areas where bending is required on free form pools and tight radiuses. Tape inside for inside corner and outside for outside corner. *Please note that the 3" filament tape is HIGHLY recommended for best results.



3

Slide clips in perforated slots on the back of the styrofoam profile. It is recommended 6-8" apart on a rectangle pool to maintain straight lines. 10-12" on a free form pool.

4

Place form with clip along the side of the fiberglass/gunite pool. Press firmly on a slight diagonal along the fiberglass (the form should be tight to the pool). Ensure there is no gap between the foam and the clip.



5

With a 1" self tapping screw drill the screw into the fiberglass.

HELPFUL HINTS:

- remove tape before pouring concrete
- use an oil spray (cooking spray) on form wall and pool wall for easy removal
- vibrate cement
- visit our Modern Moulding You Tube page for instructional video

6

Removal: Snap clips off at a 1/4 turn. It is recommended to strip off in 8' sections at a time. Use a slide hammer or a pair of vice grips in a downward angle to remove the tab remaining

Call: 519-969-8085 - mmpoolcoping.com

