



1

Start with a foam cantilever coping profile of your choice. (9 profiles to choose from)

2

Assess pool shape. Tape form in areas where bending is required on free form pools and tight radiuses. Tape inside for inside corner and outside for outside corner. *Please note that the 3" filament tape is **HIGHLY** recommended for best results.

3

Insert 8' foam piece of foam coping into the vinyl liner track. A double track is not



4

Insert Clip Horizontally into the track using the scribed lines as your guide. It is recommended 6-8" apart on a rectangle pool to maintain straight lines. 10-12" on a free form pool.

5

Rotate clip 90° vertically to lock into the track.



6

Continue installing coping piece by piece. At the joint use the clip to hold the two pieces together.

7

Pour cement and remove coping once cement has settled.

Helpful Hints:

- remove tape before pouring concrete
- use an oil spray (cooking spray) on pool wall and coping before pouring cement for easy removal
- vibrate cement
- visit our Modern Moulding YouTube Page for instructional videos.

